

HAGENMAIER DRUM - FLY ASH DECHLORINATION/ HYDROGENATION PROCESS: COMBINATORIAL BIO/CHEMICAL ANALYSIS

Peter. A. Behnisch^{1,2}, Kazunori Hosoe¹, Hironori Ozaki³,
Kazuo Nakamura⁴, Abraham Brouwer⁵ and Shin-ichi Sakai^{2,6}

¹Life Science Research Laboratories, Kaneka Corporation, Takasago, Japan

²Kyoto University, Environment Preservation Center, Kyoto, Japan

³R&D Department, Environmental Control Plant Div., Kawasaki Heavy Industries, Kobe, Japan

⁴Kyoto Municipal Government, Environment Bureau, Kyoto, Japan

⁵BioDetection Systems, Amsterdam, The Netherlands

⁶National Institute for Environmental Studies, Tsukuba, Japan

Introduction

Low temperature treatment (below 400 °C) of fly ashes under oxygen deficiency conditions (thermo-catalytic treatment or Hagenmaier process) has been already applied on several municipal waste incinerator plants in Germany^{1,2,3,4} and Japan^{5,6} as a successful method for the reduction of dioxins and related compounds.

Hagenmaier (1988)¹ obtained reductions of PCDD/Fs in a range of 95 to 99.9%, and for PCBs, chlorobenzenes and chloronaphthalenes of 93%. Also Ishida et al. (1996)⁵ reported about a decrease in the I-TEQ from 0.6 I-TEQ ng/g in untreated ash to 0.002 I-TEQ ng/g (99.7% PCDD/Fs decomposition ratio) in treated ash (350° C, 1 h retention time). In addition, Sakai (1999)⁵ also showed that TEQ-values from about 100 µg TEQ/ton waste on average (combustion technologies in 1999) could be reduced to about 3.8 µg TEQ/ton waste on average (96% treatment efficiency). This result is comparable to the also in the same study reported 4.15 µg TEQ/ton waste on average gasification melting technology. The future target in Japan for the total amount of PCDD/Fs released by regulatory standards is 5 µg TEQ/ton waste on average⁶.

The aim of the present study was to confirm the decrease of PCDD/F-TEQs, bioassay-TEQ-values (measured by Micro-EROD⁷⁻¹¹ and DR-CALUX[®]-bioassays^{12,13}) and therefore the total sum of dioxin-like activity for two fly ashes treated by the Hagenmaier process in one incineration plant.

Materials and Methods

1. Fly ash dechlorination/hydrogenation treatment

Fly ash from a fabric filter and a gas cooling tower is fed into the Hagenmaier drum for thermal dechlorination of PCDD/Fs, and afterwards treated for stabilizing heavy metals by chelate resin. The dechlorination process consists of a reactor (Hagenmaier drum) and a cooler as main equipment. Fly ash is charged into the reactor through the inlet rotary valve, heated up (at least 350° C) under exclusion of air (O₂ < 1 %; done by introducing N₂ gas). The best decontamination results were obtained in the temperature range of 350-400° C and residence time for the ash of at least 30 min.

DIOXIN REDUCTION-POSTER

2. Fly ash sampling, clean-up and analysis

Sampling (12.5-25 g untreated fly ash and 50 g treated fly ash), clean up (without oxidative clean-up) and analysis of PCDD/Fs in treated and untreated fly ash were carried out according to previous publications^{8,9}.

3. DR-CALUX[®]- and Micro-EROD-bioassay

- DR-CALUX[®]-bioassay (BioDetection Systems, BDS): The validation samples and treated/untreated fly ash samples were analysed according to the guidelines from BDS (www.biodetectionsystems.com) and recently published studies^{12,13}.
- DR-CALUX[®]-bioassay (Kaneka Corporation, KC): The samples at KC were also analysed according to a.), but the luciferase activity was measured using LucLite™ (Packard) and the TopCount NXT[®] Microplate Scintillation & Luminescence Counter (Packard).
- The Micro-EROD bioassay was performed as already published¹¹.

Results and Discussion

As cross-validation study for the DR-CALUX[®] technology, three fly ash samples (a/b/c; in ng TEQ/g) and one emission gas (d; in ng TEQ/m³) were analysed at BDS and KC. These samples were additionally analysed by chemical analysis and Micro-EROD bioassay {a/b/c/d in brackets}:

- DR-CALUX[®]-TEQ {at BDS: ashes: a=237/b=130/c=13.8/emission gas d= 97};
- DR-CALUX[®]-TEQ {at KC: 209/134/16.5/72};
- Micro-EROD bioassay {analysed at KC: -/51/5.1/8.9} and TEQ {chemical analysis at BDS or KC: 95/43/5.3/8.7}.

The resulted DR-CALUX[®] TEQ values for both laboratories were comparable.

After the cross-validation study with BDS, two untreated and four treated fly ashes (Hagenmaier process) were analysed at KC (see Table 1):

- The TEQ/EROD-TEQ/DR-CALUX[®]-TEQ values of the untreated fly ash No. 1 could be decreased from 12/18/59 ng TEQ/g to finally 0.11/0.14/- ng TEQ/g for treatment No. 1a and to 0.0018/0.0033/0.021 for treatment Nr. 1b.
- Fly ash No. 2 could be efficiently reduced from 2.1 (TEQ)/3.9 (EROD-TEQ)/2.6 (DR-CALUX[®]-TEQ) ng/g to finally 0.11/0.42/0.15 (Treatment No. 2a) and 0.017/0.022/0.021 (Treatment No. 2b).
- This resulted in a treatment efficiency for these fly ashes from 95-100 % in TEQs; 94-100% in DR-CALUX[®]-TEQs and 89-100% in EROD-TEQs.
- The Ratio between bioassay-derived TEQ and TEQ values for untreated fly ash (Micro-EROD: 1.5/1.9 and DR-CALUX[®]: 4.9/1.2) and treated fly ashes (Micro-EROD: 1.3; 1.8/3.8; 1.3 and DR-CALUX[®]: -, 12/1.4; 1.2) were similar to previously reported studies⁷⁻¹⁰.

Dose-response curves of the DR-CALUX[®] activity are shown in Graph 1 (24 h kinetic; curves were fitted using a one-ligand curve-fit; three independent measurements; EROD dose-response curves were similar).

DIOXIN REDUCTION-POSTER

Acknowledgements


The presented project was financially supported by a Grant-in-aid for the Development of Innovative Technologies from the Ministry of Education, Culture, Sports, Science, and Technology from Japan. The authors wish to thank Dr. F. Wiebel and Dr. K.W. Schramm (GSF, Germany) for providing the H4IIEC3/T cells. Shuka Matsumoto (Kaneka Corporation) and Michiko Sano (Kaneka Techno Research) are gratefully acknowledged for excellent technical assistance.

References

1. Hagenmaier H. (1988) EntsorgungsPraxis 1988, 186
2. Trumpf R., Christmann A. and Hagenmaier H. (1998) UTA International 2,82
3. Schetter G., Hagenmaier H. (1992) Pollution Prevention-Asia/Pacific Edition 1,51
4. Schetter G., Horch K., Stütze R., Brunner H., Hagenmaier H. (1990) Organohalogen Compounds 3, 165-168.
5. Ishida M., Shiji R., Nie P., Nakamura N. and Sakai S. (1996) Organohalogen Compounds 27,147
6. Sakai S. (1999) Organohalogen Compounds 40,449
7. Schramm K.W., Klimm C., Hofmaier A., Kettrup A. (2001) Chemosphere 42,551
8. Behnisch P. A., Hosoe K., Shiozaki K., Sakai S. (2000) Organohalogen Compounds 45,216
9. Behnisch P. A., Hosoe K., Shiozaki K., Sakai S. ESPR-Environ.Sci. & Pollut. Res. (submitted).
10. Till M., Behnisch P., Hagenmaier H., Bock K.W., Schrenk D. (1997) Environ Health Perspect 105,1326
11. Behnisch P. A., Hosoe K., Shiozaki K., Sakai S. (2000) Organohalogen Compounds 45, 220
12. Bovee T.F.H., Hoogenboom L.A., Hamers A.R., Traag W.A., Zuidema T., Aarts J.M., Brouwer A., Kuiper H.A. (1998) Food Add. Contam. 15, 863
13. Hamers T., van Schaardenburg M.D., Felzel E.C., Murk A.J., Koeman J.H. (2000) Sci. Tot. Environ. 262, 159

DIOXIN REDUCTION-POSTER

Graph 1: Dose-response curves of DR-CALUX[®] activity from untreated (n=2) and treated (n=4) fly ash samples (by the Hagenmaier process).



DIOXIN REDUCTION-POSTER

Table 1 : DR-CALUX[®]-T^a and T^b (PCDD/Fs)- values for treated and untreated fly ashes (Hagenmaier process) {ng T^a /g}
 [n number of measurements; SD standard deviation; CV coefficient of variation (%)]

Sample	CALUX-T [®]	ROD-T	T	CALUX-T [®] /T	ROD-T /T
Sample 1					
Untreated 1	59 [3;8;14]	18 [5;5;28]	12	4.9	1.5
Treated 1a		0.14 [5;0.06;41]	0.11		1.3
Treated 1b	0.021 [4;0.003;16]	0.0033 [5;0.0033;25]	0.0018	12	1.8
<u>Treatment efficiency [%]</u>	<u>99.96</u>	<u>100</u>	<u>99.1-100</u>		
Sample 2					
Untreated 2	2.6 [6;0.63;24]	3.9 [5;0.47;12]	2.1	1.2	1.9
Treated 2a	0.15 [4;0.17;20]	0.42 [5;0.2;47]	0.11	1.4	3.8
Treated 2b	0.021 [3;0.0005;2]	0.022 [5;0.022;25]	0.017	1.2	1.3
<u>Treatment efficiency [%]</u>	<u>94.2-99.2</u>	<u>89.2-99.4</u>	<u>94.8-99.2</u>		

^a The procedure blank (13.8 pg abs.; n=3). was at least 80-times lower lower than the lowest T value. The DMSO blank was subtracted.

^b The procedure blank (9.3 pg abs.; n=2). was at least 10-times lower lower than the lowest T value. The DMSO blank was subtracted.